



**SHERWIN  
WILLIAMS®**

**PROMAR®**

Interior/Exterior Semi-Gloss  
Block Filler and Finish

**B25W00035**

As of 10/30/2017, Complies with:			
OTC	Yes	LEED® 09 CI	Yes
OTC Phase II	Yes	LEED® 09 NC	Yes
SCAQMD	No	LEED® 09 CS	Yes
CARB	Yes	LEED® V4 Emissions	No
CARB SCM2007	Yes	LEED® V4	No
Canada	Yes	MPI	

### CHARACTERISTICS

**ProMar Interior/Exterior Semi-Gloss Block Filler and Finish** has excellent filling characteristics and is designed to provide a high build filling and finish system in one product.

**Color:** Off White

**Coverage:**

Smooth surfaces 75-125 sq ft/gal  
Rough surfaces 60-100 sq ft/gal

**Drying Time, @ 77°F, 50% RH:**

temperature and humidity dependent

Touch: 2 hours  
Recoat: 24 hours

**Flash Point:** N/A

**Finish:** 25-35 units @ 60°

**Shelf Life:** 36 Months unopened

**Tinting with CCE:**

Base	oz/gal	Strength
White	0-4	N/A

**Vehicle Type:** Vinyl Acrylic

**B25W00035**

**VOC (less exempt solvents):**

91 g/L; 0.76 lb/gal

**Volume Solids:** 38 ± 2%

**Weight Solids:** 49 ± 2%

**Weight per Gallon:** 10.21 lb

**WVP Perms (US)** 49.46

grains/(hr ft<sup>2</sup> in Hg)

### SPECIFICATION

**Masonry, Concrete, Cement, Block**

1ct. ProMar Interior/Exterior Semi-Gloss  
Block Filler and Finish

**optional**

2cts. ProMar Interior/Exterior Semi-Gloss  
Block Filler and Finish

### SURFACE PREPARATION

**WARNING!** Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (**NIOSH** approved) and proper containment and cleanup. For more information, call the National Lead Information Center at **1-800-424-LEAD** (in US) or contact your local health authority.

**Masonry, Concrete, Cement, Block**

Remove all surface contamination, form release agents, moisture curing membranes, etc. by washing with an appropriate cleaner, rinse and allow to dry. Pressure wash the surface if needed. Remove existing peeled or checked paint to a sound surface. Concrete and mortar must be cured, generally 30 days, at 75°F before painting.

Complete removal of sealers, release compounds, and to provide a profile, tilt-up and poured-in-place concrete could require sandblasting or cleaning with commercial detergents. Do not apply to smooth, slick surfaces. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.

Masonry surfaces must be dry before priming. Moisture content must be 15% or lower, and the pH between 6 and 9. If the pH is greater than 9, use Loxon Block Surfacer in place of ProMar Block Filler.

For repairing exterior cracks, bugholes, air pockets, and other voids use an elastomeric patch or seal.



# PROMAR<sup>®</sup>

## Interior/Exterior Semi-Gloss Block Filler and Finish B25W00035

<u><b>SURFACE PREPARATION</b></u>	<u><b>APPLICATION</b></u>	<u><b>CAUTIONS</b></u>
<p><b>Mildew</b> Prior to attempting to remove mildew, it is always recommended to test any cleaner on a small, inconspicuous area prior to use. Bleach and bleaching type cleaners may damage or discolor existing paint films. Bleach alternative cleaning solutions may be advised. Mildew may be removed before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach/water solution.</p>	<p>Apply at temperatures above 50°F. No reduction necessary.</p> <p><b>Brush</b> Use a nylon/polyester brush.</p> <p><b>Roller</b> No reduction necessary. Use a 3/8"-1½" nap synthetic roller cover.</p> <p><b>Spray—Airless</b> Pressure ..... 2000 psi Tip..... .019"-.028" Reduction ..... up to 1 pint water/gallon Remove all in-line and gun filters</p> <p>Apply paint at the recommended film thickness and spreading rate as indicated on front page. Application of coating below minimum recommended spreading rate may adversely affect the coating systems performance.</p> <p>ProMar Block Filler/Finish is ready-to-spray (airless) and does not require thinning. Mix material thoroughly to a uniform consistency with power agitation and apply by brush, roller, or spray. If applied by airless spray, follow by roller, being careful to force material into pores in order to reduce pinholes and produce a relatively smooth surface. Squeegee or trowel will provide the smoothest finish. Two coats properly applied may be required to provide the most uniform surface.</p>	<p>Protect from freezing. For interior and exterior use. Do not apply to damp or wet surfaces. Do not use below grade as a hydrostatic waterproofer or in immersion service.</p> <p>Before using, carefully read <b>CAUTIONS</b> on label.</p> <p>HOTW 10/30/2017 B25W00035 17 91</p> <p><u><b>CLEANUP INFORMATION</b></u></p> <p>Clean spills and spatters, hands and tools immediately with soap and warm water. After cleaning, flush spray equipment with compliant cleanup solvents to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using solvents.</p> <p>The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of The Sherwin-Williams Company. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Sherwin-Williams representative or visit <a href="http://www.paintdocs.com">www.paintdocs.com</a> to obtain the most current version of the PDS and/or an SDS.</p>